

FORD TRANSIT CONNECT


Side Sliding Door
"driver-side"

Align factory bolt in this hole.



TEMPLATE GUIDE
Vehicle:
FORD TRANSIT CONNECT


Door:
Side Sliding Door
"driver-side"



Align this edge of the template with the edge of the door.



CUT ALONG DASHED
LINES AND CIRCLES



Mark this spot for drilling
the 7/8" housing hole.

